


# SIDE OPENING ELEMENT TRIM

## Front side door trim: Removal - Refitting

# 72A



130167

- ☐ Remove the control board (4) using the tool (**Car. 1363**)
- ☐ Disconnect the supply connectors.
- ☐ Remove the front side door trim partially.
- ☐ Unclip the interior opening control cable using a flat-blade screwdriver.
- ☐ Disconnect the door sill light connector.


### REFITTING

#### I - REFITTING PREPARATION OPERATION

- ☐ If necessary, replace the clips on the front side door trim.


#### II - REFITTING OPERATION FOR PART CONCERNED

- ☐ Connect the supply connector (depending on equipment level).
- ☐ Clip on the door interior handle cable.
- ☐ Refit the front side door trim.



130168

- ☐ Connect the supply connector.
- ☐ Refit:
  - the control board (5) ,
  - the bolts (6) .



130169

- ☐ Connect the door mirror switch connector.
- ☐ Refit the trim (7) .

#### III - FINAL OPERATION.

- ☐ Check that it is working correctly.
- ☐ Clip the trim (1) onto the door mirror.