

RENAULT

Workshop repair manual

ENGINES (petrol)

4-cylinders with aluminium cylinder blocks

| Type | Range |
|------------|---|
| 829 | <i>Fuego</i> RENAULT 20 |
| J5R | <i>Trafic</i> <i>Master</i> <i>Jeep</i> RENAULT 18 |
| J6R | <i>Fuego</i> RENAULT 20 RENAULT 21 RENAULT 25 <i>Espace</i> |
| 851 | RENAULT 20 RENAULT 18 |
| J7T | <i>Fuego</i> RENAULT 21 RENAULT 25 <i>Espace</i> <i>Trafic</i> <i>Master</i> |
| J7R | RENAULT 21 RENAULT 25 |

Cancels and supersedes 1987 edition part no. 77 11 082 738

77 11 086 843

Edition Anglaise

"The repair methods given by the manufacturer in this document are based on the technical specifications current when it was prepared.

The methods may be modified as a result of changes introduced by the manufacturer in the production of the various component units and accessories from which his vehicles are constructed."

All copyrights reserved by the Régie Nationale des Usines Renault.

Copying or translating, in part or in full, of this document or use of the service part reference numbering system is forbidden without the prior written authority of the Régie Nationale des Usines Renault.

**ENGINE AND
PERIPHERAL UNITS**

CONTENTS

| | Page |
|--|-------------|
| 10 ENGINE ASSEMBLY AND LOWER ENGINE UNITS | |
| Specifications | |
| Foreword | 10-1 |
| J6R engine exploded view | 10-2 |
| J7T and J7R engines exploded view | 10-3 |
| J7R Turbo engine exploded view | 10-4 |
| J7R 720 12-valve engine exploded view | 10-5 |
| Engine identification | 10-6 |
| Cross section and tightening torques | 10-9 |
| Lubrication circuits | 10-13 |
| Specifications | 10-16 |
| Standard service exchange | 10-24 |
| Special tooling | 10-25 |
| Consumables | 10-29 |
| Cylinder head | |
| Exploded view | 10-30 |
| Cylinder head | 10-32 |
| Engine repair | 10-34 |
| Oil pressure | |
| Checking oil pressure | 10-87 |
| Oil pump | |
| Removing - Refitting | 10-88 |
| Piston base cooling jets | |
| Removing - Refitting | 10-90 |
| Strengthening base | |
| Removing - Refitting | 10-91 |
| Coolant pump | |
| Removing - Refitting | 10-93 |
